




Electric plugs

1: 2: 3:







- 1: Connection overload, located in the tower for emergency stop.
- 2: Connection control buttons, located in the tower for push buttons.
- 3: Connection buzzer, located in the tower for emergency stop.

TECHLINE

Manufacturer TECH LINE Kyrkbacken 2 SE- 507 90 Brämhult

Tel: +46 (0) 709 837972 Mob: +46 (0) 705 88 96 19

E-Post: stefan@htu-center.se

Webb: www.techline.nu